
HunterDouglas

Pull Cord Assembly Replacement Guide



Duette[®] with UltraGlide[®] Honeycomb Shades

CONTENTS

Disassemble the Shade:	
Parts (Depending upon Order)	3
Additional Parts (Depending upon Order)	3
Tools and Fasteners Needed	
Remove the Shade from the Window	
Remove the End Cap from the Headrail	4
Slide the Headrail Open	4
Remove the Pull Cord Assembly (PCA):	
Lift the PCA from the Fabric Stack.	5
Remove the Connector or Gear Assist (for Wider Shades) from the PCA	
Attach the New PCA:	
Attach the Connector or Gear Assist (for Wider Shades) to the New PCA	7
Replace the Connector or Gear Assist (If Necessary):	
Remove the Shaft and its Attached Components from the Connector or Gear Assist .	9
Insert a new Shaft Retaining Clip into the New Connector or Gear Assist	9
Insert the Shaft into the Connector or Gear Assist	10
Attach the Connector or Gear Assist to the PCA	10
Reassemble the Shade:	
Insert the Tab on the New PCA into the Fabric Hole	11
Slide the PCA into the Headrail	11
Reinstall the End Cap	12
Check for any Caught Fabric	12
Transfer the Tassel Assembly:	
Remove the Tassel from the Old PCA	13
Release the Equalizer Housing from the Tassel Cover	13
Release the Wedge from the Equalizer	14
Reassemble the Tassel to the New PCA	14
Reinstall the Shade	
Reinstall the Shade	15
Warning	16

Questions?

Call the Hunter Douglas Customer Information Center at **1-888-501-8364.**



© 2011 Hunter Douglas. ® Registered trademark of Hunter Douglas. ™ Trademark of Hunter Douglas.

DISASSEMBLE THE SHADE

Parts (Depending upon Order)

Check to make sure that you received the correct Pull Cord Assembly (PCA) that will fit your particular shade. The PCA is right or left control specific.

The three types of PCA's are:

- ³⁄₈" pleat size UltraGlide[®] PCA or,
- ¾" pleat size UltraGlide PCA or,
- 1¼" pleat size UltraGlide PCA

Additional Parts (Depending upon Order)

Connector Part # 2982021000



Shaft Retainer Clip
 Part # 2982020000



Gear Assist
Part # 2983681000




Tools and Fasteners Needed

- Small flat blade screwdriver
- Mallet
- Needlenose pliers

Remove the Shade from the Window

- Lower the shade approximately 4".
- While holding the headrail, push back on the bottom tab of the installation bracket using a small flat blade screwdriver to release the bottom edge of the headrail.
- After releasing the bottom edge, roll the back of the headrail down and out from the bracket.





DISASSEMBLE THE SHADE

Remove the End Cap from the Headrail


Tap the pull cord side end cap off with a flat blade screwdriver.

CAUTION: Be careful not to damage the end cap; you will need it for reassembly.



Slide the Headrail Open


Hold the cord against the bottom rail and slide out the PCA, fabric stack, and bottom rail far enough to expose the entire PCA.



REMOVE THE PULL CORD ASSEMBLY (PCA)

Lift the PCA from the Fabric Stack

Lift the tab on the PCA up from the fabric stack.




Remove the Connector or Gear Assist (for Wider Shades) from the PCA

Removing the Connector from the PCA

- Insert the flat blade screwdriver between the connector and the PCA.
- Slightly twist the screwdriver to remove the PCA from the connector.


NOTE: *DO NOT* throw away the old PCA. Parts from the old PCA will be used later in these instructions.



REMOVE THE PULL CORD ASSEMBLY (PCA)

Removing the Gear Assist from the PCA

- Insert a flat blade screwdriver between the gear assist and the PCA.
- Slightly twist the screwdriver to remove the PCA from the gear assist.
- If you need a new gear assist, contact the Customer Information Center at 1-888-501-8364.




Attach the Connector or Gear Assist (for Wider Shades) to the New PCA

Both the connector and the gear assist are designed to attach to the PCA.

Attaching the Connector to the New PCA

Insert the connector with the shaft and other headrail components attached, into the hole in the new PCA, rotating it back and forth to seat it securely. The connector should snap into place, flush against the PCA.







ATTACH THE NEW PCA

Attaching the Gear Assist to the New PCA

Insert the gear assist with the shaft and other headrail components attached, into the hole in the new PCA, rotating it back and forth to seat it securely. The gear assist should snap into place, flush against the PCA.






If replacing the connector or gear assist, note that both require a new shaft retainer clip.

Remove the Shaft and its Attached Components from the Connector or Gear Assist


To release the shaft, use needlenose pliers and pull the shaft retainer clip toward the connector or gear assist.

TIP: It may help to use a small flatblade screwdriver to push the shaft out of the connector or gear assist, as you squeeze the needlenose pliers.



Insert a new Shaft Retaining Clip into the New Connector or Gear Assist


Insert the shaft retaining clip into the slot in the connector or gear assist, with the flanges toward the PCA.



REPLACE THE CONNECTOR OR GEAR ASSIST (IF NECESSARY)


Insert the Shaft into the Connector or Gear Assist

Insert the shaft through the shaft retaining clip, all the way into the connector or gear assist. The end of the shaft should be seated securely, butted up against the walls of the connector or gear assist.




Attach the Connector or Gear Assist to the PCA

See "Attach the Connector or Gear Assist (for Wider Shades) to the New PCA" on page 7.



Insert the Tab on the New PCA into the Fabric Hole


The hole is 2" from the end of the fabric stack.



Slide the PCA into the Headrail

The PCA, fabric stack, and bottom rail will slide together.

WARNING: Be careful not to snag, nick, or cut the fabric or tape hanging down from the PCA.




REASSEMBLE THE SHADE

Reinstall the End Cap


Tap the end cap securely in place, then check the operation of the shade.

NOTE: Hold the fabric open so the fabric cells are not crushed.




Check for any Caught Fabric

Turn the headrail over and check the fabric. The end cap should fit snugly and will not crush or bend the fabric.




Remove the Tassel from the Old PCA

Hold the tassel cord while pulling upward on the tassel to pull out the equalizer housing.



Release the Equalizer Housing from the Tassel Cover

- Unwrap the lift tape from the old PCA from around the base of the equalizer housing.
- Pull up on the old lift tape to remove the equalizer from the housing.



TRANSFER THE TASSEL ASSEMBLY

Release the Wedge from the Equalizer

- While holding the equalizer, use a flat blade screwdriver to release the wedge.
- Unwrap the old lift tape from the equalizer and tassel cover.
- Discard the old PCA.

Reassemble the Tassel to the New PCA

Slide the tassel cover, hole-end first, onto the lift tape of the new PCA.



Loop the tape once around the equalizer.

- Insert the wedge with the rib side toward the tape and the inside of the equalizer.
- Push the wedge up until flush to lock the tape loop into place.







TRANSFER THE TASSEL CORD ASSEMBLY / REINSTALL THE SHADE

Place the equalizer into the equalizer housing.

- Re-attach the tassel cord (removed from the old PCA) by sliding the knot into the bottom of the equalizer housing.
- Wrap excess lift tape around the base of the equalizer housing. Do not wrap more than three times. Excess cord around the base will cause the tassel cover to crack.
- Slide the tassel cover firmly over the equalizer housing.
- Cut the excess lift tape so it is flush with the bottom of the equalizer housing.








Reinstall the Shade

- Position the shade so that the front side (colored fabric) faces you.
- Slip the headrail into the installation brackets so that the front of the brackets slide under the front groove on the top of the headrail.
- Gently roll the back of the headrail up and push back to snap the shade into place.



CHILD SAFETY



Young children can wrap cords around their necks and STRANGLE.

- Always keep cords out of the reach of children.
- Move cribs, playpens and other furniture away from cords. Children can climb furniture to get to cords.
- Do not tie cords together. Make sure cords do not twist together and create a loop.

Questions? Call the Hunter Douglas Customer Information Center at 1-888-501-8364 Visit our Web site at hungerdouglas.com



hunterdouglas.com

