

somfy. DECORATOR SONESSE30 SWITCH

DESCRIPTION

The Decorator Sonesse switch line is designed for use with SOMFY's Sonesse 30 dry-contact motors. This switch features a 4 wire terminal block which allows for an easy connection to the motor. Third party controllers may be easily connected to a secondary 4 wire terminal block located on the switch.



Part Number: 1800219 (White)


1800220 (Ivory)

MECHANICAL SPECIFICATIONS

Overall Dimensions: L: $4^{1}/_{2}$ in. W: $2^{3}/_{4}$ in. D: $1^{1}/_{2}$ in.

Installs in a standard single gang electrical box.

CONNECTION DIAGRAM



- **1.** Connect the Sonesse 30 motor to the low voltage terminal block as indicated.
- 2. Pressing the UP button should raise the window treatment, while pressing DOWN will lower it. To stop the window treatment at any time, simply press the STOP button.
- 3. If operation by a third party device is desired, the terminal blocks can be used as a connection point. A momentary contact between the UP and COM terminals will activate the Up command. Similarly, connecting the DWN and COM terminals will activate the Down command. To activate a Stop command, a momentary contact between STOP and COM in needed.
- **4.** The Dry Contact Switch can be used to establish the following motor settings:
 - Upper and lower motor limits
 - Intermediate Stop (MY) position
 - Motor speed control

REF. NO: 2500030

- Rollup and Tilt Features

SOMFY CANADA

6315 Shawson Drive, Unit #1 Mississauga, Ontario L5T1J2

SOMFY SYSTEMS, INC.

47 Commerce Drive Cranbury, NJ 08512